

WARRANTY AND AFTER SALES SERVICE

The warranty period is one year from the date of receiving the product. Under the warranty period and conditions, the company will provide a full range of warranty services in accordance with the provisions of the product failure and abnormal problems:

1. Free repair of faulty machines
2. Free replacement of faulty parts (except burr)
3. Items stipulated by laws of other countries

EXCEPTIONS

Product failure or damage in one of the following situations is not covered by the warranty.

1. Product failure caused by using accessories other than our company;
2. Product failure caused by dismantling the machine without authorization;
3. Product failure caused by failure to operate in accordance with the instructions;
4. Obtain the product by illegal means or means;
5. Product failure caused by force majeure;
6. Products repaired by unauthorized third party personnel without contacting the company and its authorized dealers.

APPLICATION AND USAGE

the appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction
- children being supervised not to play with the appliance

Instructions include the operating times and speed settings for accessories;


The instructions include details on how to clean surfaces in contact with food.

This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments.

if the manufacturer wants to limit the use of the appliances to less than the above, this has to be clearly stated in the instructions.

AMX COFFEE GRINDER DF64 INSTRUCTIONS



Please read this manual and keep it properly before using the product